


Touch-Tone Code → (\*/I/9) (Security Entry Window)  
 \*192 = Repeater Enable (ON)  
 \*193 = Repeater Disable (OFF)

DPDT  
 1 - Latching relay  
 1 - DPDT relay

Section PER RADIO UHF-VHF  
 449.500/  
 146.04/64

Lambda Power Supply



Touch-Tone Code → (\*I/9) (Security Entry Window)  
 \*192 = Repeater Enable (ON)  
 \*193 = Repeater Disable (OFF)

Section PER RADIO UHF-VHF  
 449.500/  
 146.04/64

W6BAMT/WABNEH	Lambda Power Supply
Fran Diego Repeater Assn	+12/5A
Oct. 1976 MT OYAY	+24/1A